

Welcome to Payanywhere.

3-in-1 Bluetooth® Credit Card Reader

(PAX D135)



Get started.

For help with your first-time setup, call 888.579.4787



3-in-1 Bluetooth® Credit Card Reader

Contactless | EMV chip cards | Magstripe cards

What's in the box:

1. Credit card reader
2. Charging cord

Download the Payanywhere app



Connect your reader.

 We recommend you fully charge your reader before connecting with the app.

Apple iOS

1. Launch the Payanywhere app.
2. Log in using the QR code provided in your Welcome email. Or, log in with the email address and password you used when creating your account.
3. Go to Menu (≡) → Settings → Card Readers.
4. Select your reader ("D135-xxxxxxxxxxxx") to pair it to the app.

Android

1. Launch the Payanywhere app.
2. Log in using the QR code provided in your Welcome email. Or, log in with the email address and password you used when creating your account.
3. Go to Menu (≡) → Settings → Card Readers.
4. Select your reader ("D135-xxxxxxxxxxxx") to pair it to the app.
5. You will be prompted to give your device permission to connect to the reader.

 Order additional readers at paymentshub.com.

Complete a sale.



Tap (Contactless payments)

Tap the Contactless Payment button on the Payanywhere checkout screen. With the contactless icon on the reader facing towards you, hold an NFC-enabled device or credit card within 4 centimeters of the reader.



Dip (EMV chip cards)

The chip should face the same direction as the NFC icon.



Swipe (Magstripe cards)

The front of the card should face the same direction as the NFC icon.

Accept payments.


Choose a theme

Payanywhere's default Terminal theme works just like a traditional credit card terminal. For advanced features like inventory and open tabs, switch to the Retail theme. You can change your theme by navigating to Settings → Theme.



Terminal theme

1. Enter a dollar amount on the New Sale screen.
2. Insert an EMV chip card into the reader. Or, select the desired payment method at the bottom of the screen.
3. Your customer will sign and tip, if necessary.
4. Email, print, or SMS text a receipt to your customer.



Retail theme

1. Add one or more items to your cart. Tap Charge to proceed to checkout, or tap Create Ticket to create an open ticket.
2. Insert an EMV chip card into the reader. Or, select the desired payment method from the Checkout screen.
3. Your customer will sign and tip, if necessary.
4. Email, print, or SMS text a receipt to your customer.

Access Payments Hub.



Log in

Payments Hub is the online hub to manage your business. Navigate to paymentshub.com and log in with the email address and password you used when creating your account.

View activity

See real-time sales data, transactions, deposits, statements, and generate reports.

Create employees

Assign administrators, managers, cashiers, or reporters with customizable levels of access.

Manage account

Update your personal and business information, manage disputes, and integrate with third-party services.

Accept payments

Process credit card payments in a web-based virtual terminal. Send recurring invoices that customers pay online.

Manage inventory

Build or import a product library and track stock. Create items with price variants, categories, modifiers, and discounts.

Order supplies

Purchase receipt paper, hardware, and accessories.

Tips and troubleshooting.

1. Check that the magstripe or chip of the card is facing the right direction.
2. Check to see if your reader is fully charged. If it is at a lower battery level, connect to the USB C cable to charge. The flashing red LED light will turn green when the reader is finished charging.
3. Restart your reader by pressing the power button.

Learn more.



Help and tutorials

payanywhere.com/help
youtube.com/payanywhere



Customer support

custservice@payanywhere.com
877.387.5640



Product feedback

feedback@payanywhere.com

FCC Declaration of Conformance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

©2024 Payanywhere. All rights reserved. Payanywhere is a registered DBA of EPX, a registered ISO of BMO Harris N.A., Chicago, IL, Citizens Bank N.A., Providence, RI, The Bancorp Bank, Philadelphia, PA, and FFB Bank, Fresno, CA.